



Mesh Bouncer Instruction Manual

Parts List

(A) 1 x Rear Bar




(B) 1 x Left Leg




(C) 1 x Right Leg

(D) Seat Support & Fabric Cover




Step 1

Insert rear bar onto left and right legs



Step 2


Insert Seat Support (D) into leg frames (C) & (B)
Apply pressure to slide the metal seat frame to insert into the leg frame completely.



Step 3

Pull fabric cover over the ring on leg frames (A) & (B) to secure the fabric.

NOTE: This will lock the frame and hold the bouncer in place.



Put pressure on the middle of the mesh seat to ensure the frame is properly assembled. If your frame is missing parts or damaged, do not use.

According to the Baby Centre UK, you can put your newborn baby in the mesh bouncer for short periods, provided they have sufficient neck support and are secured firmly with the harness. A padded cover can be purchased to provide your newborn baby with additional support. Your baby will probably enjoy the mesh bouncer most between 3 & 6 months.

WARNING

- Never leave child unattended or in the care of other children
- Secure baby firmly using the harness provided
- Harness can be adjusted using the straps
- Must be used on a firm flat floor
- Do not use on a raised floor or raised surfaces
- Bouncers are not intended for use when your baby is able to sit upright or when they exceed 8kgs